








MARDI GRAS  
277



MARDI GRAS  
277

NOTICE.  
THIS GAME OPERATES ON  
24 VOLTS.

**WIRE COLOR CODE**

1 RED  
2 BLUE  
3 YELLOW  
4 WHITE  
5 GREEN  
6 BLACK  
7 GREY  
8 BROWN  
9 ORANGE  
0 NON-CONNECTED

**EXAMPLE:**  
S1 = WHITE-WIRE USED AS BROWN

**WORD ABBREVIATION:**

RE. RELAY  
R.D. ROTARY DRUM  
E.O.S. END OF STROKE  
S.U. START UNIT  
L. LEFT  
R. RIGHT  
MOTOR  
MOTOR  
AMP. AMPERAGE  
G.O. GAME OVER  
P.T. POINT  
L.I.B. LIBERAL  
COIN. COIN  
ADV. ADVANCE

**DOUBLE THROW:**  
A-B WHEN P-C CLOSED  
A-B WHEN P-C OPENED

**NORMALLY CLOSED:**  
A-B WHEN P-C CLOSED  
A-B WHEN P-C OPENED

**NORMALLY OPEN:**  
A-B WHEN P-C CLOSED  
A-B WHEN P-C OPENED

**LATCH RELAYS ARE DRAWN IN TRIP POSITION, UNLESS OTHERWISE NOTED.**