

TO CHANGE COIN INTAKE PLATES

REMOVE ONLY THE TOP SECTION
OF DOOR FRAME HELD BY THREE CARRI-
-AGE BOLTS.

