

TO CHANGE COIN INTAKE PLATE

REMOVE ONLY THE TOP SECTION
OF DOOR FRAME HELD BY (3) CARRIAGE BOLTS.

