

BALL COUNT UNIT DISC

DURING RESET CYCLE, THIS UNIT RESETS TO ZERO AND WHEN ADVANCES 5 STEPS.

DURING PLAY, IF "U.S.A. - ITALIAN" ADJUSTMENT IS IN "U.S.A." POSITION, THIS UNIT ADVANCES EACH TIME HE INDICATED HI-SCORE IS MADE.

TO ELIMINATE AWARDING OF EXTRA BALLS ON HI-SCORE, WHEN "EXTRA BALL-NOVELTY" ADJUSTMENT JACK IS IN "NOVELTY" POSITION, ALL PHONE TIPS MUST BE REMOVED FROM HI-SCORE ADJUSTMENT JACK".

VIEW LOOKING AT WIPER FINGERS WITH WIPER IN RESET POSITION.

