

TO CHANGE COIN INTAKE PLATES

REMOVE ONLY THE TOP SECTION
OF DOOR FRAME HELD BY THREE CARR-
-IAGE BOLTS.

