

SOCCER MOTOR SWITCHES

MOTOR 1A	Inside Sw. Second Sw. Third Sw.	<ul style="list-style-type: none"> - Resets score units. - Adds player unit. - Scoring.
MOTOR 1B	Inside Sw. Second Sw.	<ul style="list-style-type: none"> - 1st player match. - Bonus score control switch.
MOTOR 1C	Inside Sw. Second Sw. Third Sw. Fourth Sw. Fifth Sw. Sixth Sw.	<ul style="list-style-type: none"> - Motor runout. - Opens circuit to coin chute switches and replay button. - Opens circuit to hole, trough and ball return switches. - Opens circuit to "XB" relay. - Opens circuit to playboard lights. - Opens circuit to playboard contacts.
MOTOR 2B	Inside Sw. Second Sw.	<ul style="list-style-type: none"> - "D", "E", "O", "P", "Q", "S", "U", and "W" relay lockins. - "G" and "K" relay lockins.
MOTOR 2C	Inside Sw. Second Sw. Third Sw. Fourth Sw.	<ul style="list-style-type: none"> - Coin chute credit totalizer. - Bonus score control switch, 3 ball only. - Add player unit control switch. - Actuates "U" relay.
MOTOR 3B	Inside Sw. Second Sw. Third Sw.	<ul style="list-style-type: none"> - Resets control bank. - 2nd player match. - Actuates "PB", "SB1", total player meter and subtracts replay unit.
MOTOR 3-1/2B	Switch	<ul style="list-style-type: none"> - Brake.
MOTOR 3D	Switch	<ul style="list-style-type: none"> - Actuates yellow hole kicker.
MOTOR 4B	Inside Sw. Second Sw. Third Sw.	<ul style="list-style-type: none"> - Coin chute credit totalizer. - Bonus score control switch. - Adds or subtracts bonus unit.
MOTOR 4C	Inside Sw. Second Sw. Third Sw. Fourth Sw.	<ul style="list-style-type: none"> - Coin chute credit totalizer. - Actuates "QB" relay. - Actuates red hole kicker. - Actuates ball return.